





Quick Start Manual

Copyright © 2016-2019 Garmin Ltd. or its subsidiaries. All rights reserved.

This manual reflects the operation of System Software version 3.50 or later. Some differences in operation may be observed when comparing the information in this manual to earlier or later software versions.

Garmin International, Inc., 1200 East 151st Street, Olathe, Kansas 66062, U.S.A.

Aviation Support: www.fly.garmin.com

Garmin AT, Inc., 2345 Turner Road SE, Salem, OR 97302, U.S.A.

Aviation Support: www.fly.garmin.com

Garmin (Europe) Ltd., Liberty House, Hounsdown Business Park, Southampton, Hampshire SO40 9LR U.K.

Aviation Support: www.fly.garmin.com

Garmin Corporation, No. 68, Zhangshu 2nd Road, Xizhi District, New Taipei City, Taiwan

Aviation Support: www.fly.garmin.com

www.garmin.com

Except as expressly provided herein, no part of this manual may be reproduced, copied, transmitted, disseminated, downloaded or stored in any storage medium, for any purpose without the express written permission of Garmin. Garmin hereby grants permission to download a single copy of this manual and of any revision to this manual onto a hard drive or other electronic storage medium to be viewed for personal use, provided that such electronic or printed copy of this manual or revision must contain the complete text of this copyright notice and provided further that any unauthorized commercial distribution of this manual or any revision hereto is strictly prohibited.

Garmin®, aera®, ANT+®, FliteCharts®, SafeTaxi®, and MapSource® are registered trademarks of Garmin Ltd. or its subsidiaries. These trademarks may not be used without the express permission of Garmin.

This product is ANT+® certified. Visit www.thisisant.com/directory for a list of compatible products and apps.

Jeppesen® is a registered trademark of Jeppesen, Inc.

NavData[™] is a trademark of Jeppesen, Inc.

AC-U-KWIK® is a registered trademark of Penton Business Media, Inc.

IFT: RCPGAAE16-0525



















UNIT OVERVIEW



Unit Overview

Installing the battery:

- 1) Locate the lithium-ion battery that came in the product box.
- 2) Locate the metal contacts on the end of the lithium-ion battery.
- 3) Insert the battery so that the metal contacts on the battery line-up with the metal contacts inside the battery compartment.
- 4) Insert the battery into the battery compartment, and push until it clicks into place.



Unit Overview - Battery

Charging the unit's battery using the aircraft's power outlet:

- 1) Mount the aera 660 in the aircraft and connect the power cable to the aircraft power outlet (cigarette lighter receptacle).
- 2) Route the power cable so that it does not interfere with aircraft operation. The unit begins charging as soon as external power is applied.

GPS RECEIVER STATUS

The bars located at the top of the screen indicate the GPS signal strength.

Viewing the GPS status:

From the **Main Menu**, touch **GPS Info** > **GPS** tab.

DISPLAY ORIENTATION

The aera 660 can be viewed in either Portrait or Landscape Mode.

Changing the display orientation:

1) From the Main Menu, touch Tools > Setup > DisplayOr:


Press the Power Button once quickly.

2) Touch Landscape or Portrait.

OPERATION

DEDICATED PAGE ICONS

Dedicated Page Icons are located vertically on the right side of the screen in landscape mode or horizontally along the bottom of the screen in portrait mode.





Back

- Previous Screen
- Main Menu (Touch and Hold)



Cancel map pointer

MAIN MENU



Touch the following icons to display the associated page or menu:

Map Displays the Map View

Charts Displays the VFR or IFR charts.

3D Vision Displays 3D Vision.

Nearest Displays the Nearest Page.

Waypoint Displays Waypoint Information.

Flight Plan List Displays the Flight Plan List.

Active Flight Plan Displays the Active Flight Plan.

Traffic Displays the dedicated Traffic Page.

Terrain Displays the Terrain View.

Weather Displays Weather Map Page.

GPS Info Displays current position and satellite status.

Tools Displays second-level Tools Icons.

Touch and hold the licon at any time to display the Main Menu.

NEAREST ICONS

From the **Main Menu**, touch the icon to access the Nearest Page.

Touch these Nearest Group Icons to display the associated function:

*	

Airport Displays nearest airports.



Airport WX Displays nearest airport weather.



VOR Displays nearest VORs.



NDB Displays nearest NDBs.



Intersection Displays nearest intersections.



VRP Displays nearest Visual Reporting Point (VRP) (Atlantic).



Displays nearest user waypoints. **User WPT**



City Displays nearest cities.



ARTCC Displays nearest ARTCCs (Air Route Traffic Control Centers).



Displays nearest Flight Service Stations (FSS). **FSS**




Airspace Displays nearest airspace.

WEATHER ICONS

With the Weather Page displayed, touch the **Products** icon **Products** to access the Weather Products:







Level

Lightning

SIGMET

Cloud Tops Forecast Forecasted cloud top heights.

Temps Aloft Displays Temperatures Aloft.


AIRMET Displays AIRMETs.

Displays where icing conditions are likely. Freezing Level

Cloud Tops Displays cloud top height contours.

Lightning Displays lightning data.

SIGMET Displays SIGMETs.



TOOLS

From the Main Menu, touch the Tools Icon to access the second-level Tools icons.

Touch the following second-level icons to display the associated function:

* \$\psi\$	Setup	Displays third-level Setup Icons.
	User WPT	Displays User Waypoints and Proximity Waypoints.
	Flight Log	Displays Flight Logs.
to	Track Log	Displays Track Logs.
	VNAV	Displays Vertical Navigation.
1	Profile	Displays Aircraft Profiles.
	E6B	Displays the E6B Calculator.
<u>-I-</u>	Weight/Bal	Displays the Weight & Balance.
*	Data Link	Displays the Data Link Info Page.
	Downloads	Displays available downloads.
1	SiriusXM Audio	Displays the Sirius XM Audio Page.
001011011 10111000 010001101	Database	Displays database and software version information.



User Timer Displays User Timer.

VIRB Displays VIRB Remote Page.

Simulator Drives simulator.

SETUP ICONS

From the **Main Menu**, touch the **Tools** Setup l to access the thirdlevel Setup Icons. Touch these third-level icons to perform the associated function:

Display Displays backlight intensity/timeout, color mode (map/chart),

screenshot (on/off), and aircraft position settings.

Sound Displays sound settings.

Units Displays unit settings.

Time Displays time settings.

Map Displays Navigation Map settings.

Position Displays position settings.

Interface Displays interface settings.

Alarms Displays alarm settings.

Displays Special Use Airspace alarm settings. **Airspace**

) (() **Connext®** Displays Connext interface settings.

Displays weather data source setting. Weather

Bluetooth® Displays Bluetooth connection settings.

Wi-Fi Displays Wi-Fi settings.

Displays Power Loss Warning settings. **Power**

3D Vision Displays 3D Vision settings.

Navigation Displays Navigation settings

Keyboard Displays Keyboard settings.

OPTION MENUS

The aera 660 has a dedicated Icon that displays a context-sensitive list of menu options available.

Navigating the option menu:

- 1 Touch the Menu Icon
- 2 Touch the desired menu option.



DATA ENTRY

Enter

Symbol

The following icons are displayed in the data entry window.

Enter Exits the keypad function and accepts the changes.

Backspace Erases the current data.

Numeric/Alpha/ Displays the numeric, alpha, or symbol keypad.

Symbol

Cancel Cancels a value that has been edited.

Entering alphanumeric data:

• When alphanumeric data can be entered, a keypad will appear after touching the desired datafield.

Touch the keypad letters or numbers to enter the desired data.

3 Touch Enter.



Pointer GPS 12:38Å 🦚 Мар KGPH MIDWEST NATIONAL AIR CENTER Zoom Out KMCI INDEPENDENCE Zoom In KANSAS CITY INTL 1027ft MSL AvGas: \$7.89 KANSAS CITY OVERLAND PARK -D+ Direct To Menu **Airport Info** 360% 25.1% KMCI 00:16:45 1027: MSL Return Time En Green Arrow Indicat-Lat/Lon at the Мар Route to the ing Multiple Features Pointer Location Featūre are Present at the Pointer from Button Map Pointer Location the Aircraft's Elevation at Present Posithe Pointer Bearing to the Pointer tion Location from the Distance to the Pointer Aircraft's from the Aircraft's Present Present Position Position

Cancel Map

Map Panning (Navigation Map)

Activating the map pointer:


- **1)** While viewing a Map Display, touch anywhere on the map to activate the map pointer.
- 2) Touch the return icon to cancel the map pointer.

Panning the map:

While viewing a Map Display, touch anywhere on the map and drag.

Reviewing information for a map feature:

- While viewing a Map Display, touch anywhere on the map to activate the map pointer. When the Map Pointer is over a map feature, the map feature is highlighted, an information box appears on the map, and the highlighted map feature is displayed on the Map Feature Button. If multiple features are present at the Map Pointer position, green arrows will appear on the Map Feature Button.
- 2 If necessary, touch the buttons to cycle through the list of map features present at that position. Touching the buttons changes the highlight and description.
- 3 Touch the Map Feature Button to review information for the Map Feature.
- If desired touch Direct-to → to navigate to the map feature.





BLUETOOTH®

Connecting/Pairing to a weather/traffic/audio device via Bluetooth:

- 1) Ensure the weather/traffic device is turned ON. From the **Main Menu**, touch **Tools** > **Setup** > **Bluetooth** > **On**.
- **2)** Touch **Not Paired** or **Not Connected** next to the device. A Bluetooth Passkey window will open.
- **3)** Touch **OK**. The weather/traffic device is now connected.


'EASY UPDATE' DATABASE DOWNLOADING AND INSTALLATION (AUTOMATED AND USER-INITIATED)

Database purchases are available online (www.fly.garmin.com). However, once the databases are purchased online, the ability to download and install databases is available from the aera 660 via Wi-Fi.

Database downloads can be automatically downloaded as updates become available, or be user-initiated.

Enabling automated database downloads:

- 1) If Automatic Database Downloads are currently disabled, from the Main Menu, touch Tools > Downloads.
- 2) Touch **Enable Automatic Downloads**. This enables the unit to automatically download databases as they become available. The user is prompted when a database is ready for installation.



Enabling Automatic Downloads

User-Initiated database download/install:

- 1) From the Main Menu, touch Tools > Downloads.
- 2) Touch **Easy Update** to begin downloading all updated databases. Databases will continue to download even if the **Downloads** page is not displayed.



Database Downloads Page

3) Use unit as normal, following prompts as necessary.


SOFTWARE UPDATES

In addition to databases, the aera 660 will check for software updates when connected to the internet over Wi-Fi. The aera 660 can use Wi-Fi to update its system software, as well as any other software available from Garmin.

Software downloads can be either user-initiated or configured to automatically download as updates become available.

User-Initiated software download/install:

- 1) From the Main Menu, touch Tools > Downloads.
- 2) Touch Menu > Software Downloads.
- **3)** Touch the desired software update and touch **Next**.
- 4) Read the Software License Agreement and touch Agree and Install.



Software Downloads Page

Enabling automated software downloading:

- 1) If Automatic Software Downloading is currently disabled, from the Main Menu, touch Tools > Downloads.
- 2) Touch Menu > Software Downloads > Menu.
- 3) Touch Yes.



Enabling Automatic Software Downloads

Automated software download/install:

If Automatic Software Downloading is currently enabled (refer to previous procedure), a 'Update Software' window is automatically displayed once a software update becomes available.

- 1) From the 'Update Software' window, touch **Yes** to view the update.
- **2)** Touch the desired software update and touch **Next**.
- **3)** Read the Software License Agreement and touch **Agree and Install**.



Garmin International, Inc. 1200 East 151st Street Olathe, Kansas 66062, U.S.A.

Garmin AT, Inc. 2345 Turner Road SE Salem, OR 97302, U.S.A.

Garmin (Europe) Ltd. Liberty House, Hounsdown Business Park Southampton, Hampshire SO40 9LR U.K.

Garmin Corporation No. 68, Zhangshu 2nd Road Xizhi District, New Taipei City, Taiwan

Aviation Support: www.fly.garmin.com www.garmin.com